


ALIGN

POWER TABLE FEED OPERATION MANUAL

AL/CE-300S

AL/CE-400S

AL/CE-500S



No. G00474A

CONTENT

PAGE	INDEX
1	SPECIFICATION
2	WARNING
3	HOW TO INSTALL THE LONGITUDINAL FEED
4	HOW TO INSTALL CROSS FEED
5	HOW TO INSTALL KNEE LIFT FEED
6	ASSY-LIMIT ASSEMBLY
7,8,11~13	PARTS LIST
9,10	SCHEMATIC DIAGRAM OF PARTS
14,15	CIRCUIT DIAGRAM
16	HOW TO INSTALL TRANSMITTER OF TR-1
17	HOW TO INSTALL TRANSMITTER OF TR-2
18	TROUBLE SHOOTING

CONGRATULATIONS ON YOUR NEW PURCHASE OF OUR POWER FEED

Please read this manual carefully before installation and using it. It will also help you to solve some easy problems by yourselves. Hope our product will bring you more effective and joyful working.


SPECIFICATION

Model	P.P.M	Max P.P.M	Bevel Drive Gear Rate	Max Torque	Rated Voltage	Rated Current
AL/CE-500S(X,Y,Z)	4~160	160	4.8 : 1	650 in-lb	110V 50/60Hz	1Amp
AL/CE-400S(X,Y,Z)	0~200	200	4 : 1	550 in-lb	110V 50/60Hz	0.8~0.9Amp
AL/CE-300S(X,Y,Z)	0~140	200	4 : 1	440 in-lb	110V 50/60Hz	0.5~0.6Amp

VOLTAGE AS 220V-440V HAVE TO ADOPT TRANSFORMER

WARNING

Please make sure if power supply be turned off before assembly, and avoid from accident caused during procedure of assembly.



Please don't disassemble for fixing or refitment and free from accident or break down caused by unhealth assembly.




Please take apart the drill and remove worked item before assembly.



Please make sure input voltage for power feed as A.C.110V and avoid wrong power then burn down circuit board, except A.C. 110V, please adopt the transformer.




Please adjust suitable length of cord and watch out the wiring, never pressure power cord by clog then ambroin broken case short or spark.



Please don't set the power feed in excessive wetish working zone and don't wash down the power feed by water or water shipped then cause short or spark.




HOW TO INSTALL THE LONGITUDINAL FEED(X TYPE)



HOW TO INSTALL CROSS FEED(Y TYPE)

HOW TO INSTALL T-WAY TRACK FOR CROSS-FEED




T-way bar and bracket for limit switch are designed for simple installation on cross slide.


FIXED SUPPORT
T-WAY TRACK
STOP BLOCK

INSTALLATION INSTRUCTIONS


For ideal installation. You should not modify the cross travel lead screw.




HOW TO INSTALL T-WAY TRACK FOR KNEE-LIFT FEED



HOW TO INSTALL KNEE LIFT FEED(Z TYPE)



Note : Remove hand crank, dial, dial socket, bearing flange and...Etc.



Note : Install extension shaft.


Important :

1. Shaft end must be against inner ring of bearing.
2. Inner shaft is 16 or 18 threaded unc.



Note : Tighten stand to flange then tighten knee feed on the flange.


Important : For angular positioning.



Note : Install gear key not in.


Important : Use hand to push & turn bevel gear to check backlash.

1. If necessary add a few shims to obtain proper backlash.
2. Modify leading edge of gear to obtain proper backlash. Then repack gear with grease. Replace gear then push and turn to check for backlash.



Note : Remove the bevel gear after STEP 4 is O.K. then install key, replace gear, install dial, and tighten dial nut. Add a few shim if dial is grinding the gear.

Important : Pack with grease before installing the gear. Do not use silicon-type grease.



Note : Install checkclutch against bevel gear then drive through one hole of 5mm Dia. Then drive spring pin.


Important : Be sure you have followed each step carefully and correctly before installing the spring pins.

Suggestions : Install hand crank rotate in clockwise direction to check for proper shimming and that there is no binding action.



Note : Install spring handcrank (already installed), then tighten washer and screw.

Important : For operational safety, please lubricate this part and install as per instructions.



ASSY-LIMIT ASSEMBLY

CAUTION

- 1.It will damage the gear of power feed if you suddenly change the direction of power feed by pushing the direction control handle while the machine is under high-speed operation. If you intend to change the direction, please push the handle to the "off" position. Waiting until the machine is completely stopped, then push the handle to your intended direction.
- 2.Please make sure the position of the stop screw for your milling machine is keeping on "loose" status.
- 3.While the power feed is under operation, please don't change to use manual control the direction suddenly.
- 4.POWER FEED can only move to one direction.
Check : If ASSY-LIMIT SWITCH is normal.
- 5.Touch ASSY-LIMIT SWITCH POWER FEED in-between the TABLE and unable to stop it.
CHECK : If ASSY-LIMIT SWITCH is normal.

PARTS LIST

NO.	PART NAME	PART NO.	SPECIFICATION	REMARK
1	TOP HOUSING	P01807		AL/CE-500S
	TOP HOUSING	P01824		AL/CE-300S/400S
2	BEVEL GEAR NUT	A0100-01		
3	WASHER	A0100-02A	0.2x Φ 34x Φ 45mm	
4	WASHER	A0100-02B	0.4x Φ 34x Φ 45mm	
5	WASHER	A0100-02C	0.6x Φ 34x Φ 45mm	
6	WASHER(COPPER)	A0100-02D	0.1x Φ 34x Φ 45mm	
7	WASHER	A0100-04A	0.2x Φ 16x Φ 23.5mm	
8	WASHER	A0100-04B	0.4x Φ 16x Φ 23.5mm	
9	WASHER	A0100-04C	0.6x Φ 16x Φ 23.5mm	
10	WASHER(COPPER)	A0100-04E	0.1x Φ 16x Φ 23.5mm	
11	WASHER	A0100-07A	2x Φ 16x Φ 25.4mm	
12	WEEDLE BEARING	A0101A		
13	INNER RING	A0101B		
14	NEEDLE BEARING	A0101C		
15	CIRCUIT BREAKER	A0102		
16	CAP OF CIRCUIT BREAKER	A0102-01		


PARTS LIST

NO.	PART NAME	PART NO.	SPECIFICATION	REMARK
17	BUSHING BEARING	A0103	Φ 6XΦ 12X11.5mm	
18	AL DRIVE GEAR SHAFT	A0106		AL/CE-300S/400S
	SPDRIVE GEAR SHAFT	P01022		AL/CE-500S
19	AL DRIVE GEAR	A0106V		AL/CE-300S/400S
	SP DRIVE GEAR	P01021		AL/CE-500S
20	SPACER	A0109		
21	LIGHT TRANSMITTER	A0110		
22	HEX.SEAL BOOT	P01817		
23	NUT FOR RAPID SWITCH	A0111-01A		
24	RAPID SWTCH PLUNGER	A0111-02		
25	SPRING FOR RAPID SWITCH	A0111-03		
26	RAPID SWTCH HOUSING	A0111-04		
27	RAPID SWTCH ASSY	A011115		
28	SPRING FOR TOP HOUSING	A0112		
29	ADAPTOR	P01808-03		
30	SPRING FOR ALUTCH	A0301-05		
31	WASHER TRA	A0301-06	512	
32	WASHER BEARING NTA	A0301-07	512	
33	BEARING CUP	A0301-08		
34	LIFTFORK	A0301-09		
35	WASHER	A0301-10	1XΦ8XΦ18mm	
36	SHAFT MOUNT	A0301-12A		
37	WIRE	ALW-25-1	24AWGX L59mm	
38	WIRE	ALW-26	18AWGX L50mm	
39	WIRE	ALW-3	22AWG	
40	WIRE	ALW-6	22AWGX L116mm	
41	WIRE	ALW-7	22AWGX L160mm	
42	WIRE	ALW-8	22AWGX L100mm	
43	WIRE	ALW-9	22AWGX L100mm	
44	BEARING	B00001	627ZZ	
45	BEARING	B00006	608ZZ	
46	MICRO SWITCH HOLDER	C0501		
47	MICRO SWITCH ASSEMBLY	C0501-6P		AL/CE-300S
	MICRO SWITCH ASSEMBLY	C0501-6V		AL/CE-400S/500S
48	SWITCH ACTURATOR	C0502		
49	MICRO SWITCH	C0504	3P	AL/CE-400S/500S
	MICRO SWITCH	C0504-1	2P	AL/CE-300S


PARTS LIST

NO.	PART NAME	PART NO.	SPECIFICATION	REMARK
50	CAPACITOR	C0506		
51	MICRO SWITCH HOLDER	C0507		
52	MICRO SWITCH ASSEMBLY	C0508		
53	MOUNTING PLATE	C0505-01		
54	MICRO SWITCH	C0508-02		
55	BOTTOM COVER	P01809		AL/CE-500S
56	BOTTOM HOUSING	P01806		
57	400S/500S CAM ASSEMBLY	E0902V		
	300S CAM ASSEMBLY	E0902P		
58	CARBON BRUSH HOLDER	P01004	4.8X6.6X22.5	
59	BRUSH	E0905	4.3X6.2X16	
60	ON-OFF SWITCH	E0907		
61	CAP OF ON-OFF SWITCH	E0907-01		
62	WASHER	E0907-02		
63	SPRING WASHER	E0910	627	
64	SET SCREW	E0911	1/4 "X1/4"	
65	SPEED CONTROL KNOB	P01811-03		
66	HANDLE KNOB	P01812-03		
67	180 ° CONTROL HANDLE	P01810-1		X Axis
	90 ° CONTROL HANDLE	P01816-1		Y/Z Axis
68	INNER RING	E0913A		
69	CIRCUIT BOARD INSULATOR	E0915V		
70	400S/500S CIRCUIT BOARD ASSEMBLY	E0916VS		AL/CE-400S/500S
	300 CIRCUIT BOARD ASSEMBLY	JC2HS		AL-300S
	CE CIRCUIT BOARD ASSEMBLY	JC5HS		CE-300S
71	STRAIN RELIEF	E0917		
72	LIFT FORK SHAFT	E0922		
73	AL ARMATURE ASSEMBLY	E0925V-0		AL/CE-400S/500S
	SP ARMATURE ASSEMBLY	P01907		AL/CE-500S
74	400S/500S MOTOR FIELD	E0926V		AL/CE-300S/400S
	300S MOTOR FIELD	E0926P		AL/CE-300S
75	BEARING MOUNT	E0927A		
76	BUSHING	E0928	Φ 8XΦ 14.8X20	
77	STRAIN OF POTENTIOMETER	E0929-01		

SCHEMATIC DIAGRAM OF PARTS



SCHEMATIC DIAGRAM OF PARTS



3~10	148	147	150
11	149	146	

PARTS LIST

NO.	PART NAME	PART NO.	SPECIFICATION	REMARK
78	RING OF POTENTIOMETER	E0929-02		
79	CAP OF POTENTIOMETER	E0929-03		
80	WASHER OF POTENTIOMETER	E0929-04		
81	NUT OF POTENTIOMETER	E0929-05		
82	400S/500S POTENTIOMETER	E0929V	10K Ω	AL/CE-400S/500S
	300SPOTENTIOMETER	E0929P	500K Ω	AL/CE-300S
83	POWER CORD	E23017	0.75x3Cx2.7M	
84	CRESCENT RING	E0934-01	S38	
85	WASHER	E0934-02	1.5x ϕ 38x ϕ 54	
86	SPRING WASHER	E0934-03	6205	
87	HUB OF ZYTEL GEAR	E0934-04		
88	CRESCENT RING	F01001	IR24	
89	E-RING	F10040	E4	
90	E-RING	F10050	E5	
91	MICRO SWITCH	F1104		
92	CONTROL CORD	E24002	0.75x4Cx1.7M	AL/CE-400S/500S
	CONTROL CORD	E23015	0.75x3Cx1.7M	AL/CE-300S
93	TRAVEL STOP	G0100-011		
94	NUT	G0103		
95	CRESCENT RING	G0106		
96	SPRING	G0107		
97	TRAVEL STOP SHAFT	G0108		
98	NUT	N10020	M2	
99	NUT	N10030	M3	
100	NUT	N22001	5/6"	
101	CARBON BRUSH CAP	E0906		
102	PLASTIC GEAR	P01007		
103	BEVEL GEAR X/Y(STANDARD)	P01017	5/8"x1/8"	AL/CE-500S
	BEVEL GEAR Z(STANDARD)	P01032	22x4mm	AL/CE-500SZ
	BEVEL GEAR	P01054	20x6	AL/CE-500S
	BEVEL GEAR X/Y(STANDARD)	P01013	5/8"x1/8"	AL/CE-300S/400S
	BEVEL GEAR Z(STANDARD)	P01014	22x4mm	AL/CE-300S/400S
104	LIMIT SWITCH COVER	P01015		
105	LIMIT SWITCH HOLDER	P01018		


PARTS LIST

NO.	PART NAME	PART NO.	SPECIFICATION	REMARK
106	ACTUATOR	P0 1019		
107	LIFTFORK RING	P0 1028		
108	HOLD PLATE	P0 1040	30°	
109	AL DRIVE GEAR ASSEMBLY	P0 1901		AL/CE-300S/400S
	SP DRIVE GEAR ASSEMBLY	P0 1902		AL/CE-500S
110	LIFTFORK ASSEMBLY	P0 1903		
111	MICRO SWITCH ASSEMBLY	P0 1904		
112	400S/500S POTENTIOMETER ASSEMBLY	P0 1905		
	300S/200S POTENTIOMETER ASSEMBLY	P0 1908		
113	ZYTEL GEAR ASSEMBLY	P0 1909		
114	LEMIT SWITCH ASSEMBLY	P0 1910		AL-400S/500S
	LIMIT SWITCH ASSEMBLY	P0 1924		AL-300S
	CE LIMIT SWITCH ASSEMBLY	P0 1925		CE-400S/500S
	CE IMIT SWITCH ASSEMBLY	P0 1926		CE-300S
115	TRAVEL STOP SET	P0 1916		
117	LIFTFORK ASSEMBLY	P0 1923		
118	SCREW	T12010	2x10mm	
119	SCREW	T13015	3x15mm	
120	SCREW	T13020	3x20mm	
121	SCREW	T13030	3x30mm	
122	SCREW	T14006	4x6mm	
123	SCREW	T14010	4x10mm	
124	SCREW	T15010-1	M5x10	
125	SCREW	T14070	4x70mm	
126	SET SCREW	T20001	3/16"x3/8"	
127	SET SCREW	T20003	5/16"x1"	
128	SET SCREW	T55035	5x35mm	
129	SET SCREW	T60001	1/4"x1"	
130	SET SCREW	T74004	4x4mm	
131	PIN	U33025	Φ 2x24.8mm	
132	PIN	U43014	Φ 3x13.7mm	
133	PIN	U33015	Φ 3x15mm	
134	PIN	U35014	Φ 5x14mm	
135	PIN	U42515	Φ 2.5x15mm	
136	PIN	U32516	Φ 2.5x16mm	


PARTS LIST

NO.	PART NAME	PART NO.	SPECIFICATION	REMARK
137	PIN	U43017	φ3x17.5mm	
138	SPRING	W04001		
139	WASHER	W10050	T1x φ 5x φ 12mm	
140	WASHER	W10080	T1x φ 8x φ 18mm	
141	WASHER	W10080-1	T0.6x φ8x φ 12mm	
142	SPRING WASHER	W20040	φ4mm	
143	NEME PLATE	D20283		
144	LIMIT SWITCH FIXTURE	P01919		
145	EXTENSION SHAFT	P01922	16t	
	EXTENSION SHAFT	P01929	20t	
146	T-WAY TRACK	A0301-15A	59.5cm	
	T-WAY TRACK	A0301-15B	66cm	
	T-WAY TRACK	A0301-15C	29.5cm	
147	ALUM STAND	PFB-01	28t	
	ALUM STAND	PFB-02	35t	
	IRON STAND	PFB-18	13t	
148	EXTENSION SHAFT	PFB-07	L69mm	
	EXTENSION SHAFT	PFB-08	L80mm	
	EXTENSION SHAFT	PFB-16	L60mm	
149	EXTENSION SHAFT RING	PFB-03	L40mm	
	EXTENSION SHAFT RING	PFB-04	L54.7mm	
	EXTENSION SHAFT RING	PFB-09	L27mm	
	EXTENSION SHAFT RING	PFB-10	L33mm	
	EXTENSION SHAFT RING	PFB-13	L30mm	
150	NUT	FFR-76A	1/2-20x14.3mm	
152	O-RING	Q00001	P20	
153	PART'S KIT (X)	P01911		
154	PART'S KIT (Y)	P01912		
155	PART'S KIT (Z)	P01913		


CIRCUIT DIAGRAM AL-300S



CIRCUIT DIAGRAM CE-300S



CIRCUIT DIAGRAM ALICE-400S.ALICE-500S




HOW TO INSTALL TRANSFORMER OF TR-1 (ONE OUTPUT)


TRANSFORMER OF TR-1 IS USED FOR 220V, 240V, 380V AND 415V THEN TRANSFER TO 110V. ATTACHING POWER PILOT LAMP AND ONE OUTPUT OUTLET.

ASSEMBLING GUIDE :

1. Make sure the voltage of working environment.
2. Choose the exact input point and well fix up.
3. Make sure whole screws of transformer are well locked.
4. Setting transformer on stable and dry wall.
5. Collecting cable and wire on the wire box of working place.
6. Keep from accident caused, don't disassemble and refit locked parts or wiring of transformer when assembly proceeding.



CIRCUIT




HOW TO INSTALL TRANSFORMER OF TR-2(TWO OUTPUT)


TRANSFORMER OF TR-2 IS USED FOR 220V,240V,380V AND 415V, THEM TRANSFER TO 110V. ATTACHING POWER SWITCH AND TWO OUTPUT OUTLET.

ASSEMBLING GUIDE :

1. Make sure the voltage of working environment.
2. Choose the exact input point and well fix up.
3. Make sure whole screws of transformer are well locked.
4. Setting transformer on stable and dry wall
5. Collecting cable and wire on the wire box of working place.
6. Keep from accident caused, don't disassemble and refit locked parts or wiring of transformer when assembly proceeding.



CIRCUIT



TROUBLE SHOOTING

THE POWER FEED DOES NOT WORK AND THE POWER INDICATOR DOES NOT GLOW :

- 1.Ensure there is no problem with power supply.
- 2.Check if the circuit breaker on the power feed unit kicked out.
- 3.Check for proper contact at the ON-OFF switch.

THE MOTOR DOES NOTWORK WHEN PUSH DIRECTION LEVER TO EITHER LEFT OR RIGHT :

- 1.Open power feed unit by loosening bottom 4 hex screws.
- 2.Check if the carbon brush is making proper contact with the armature or if carbon brush is all used up already.
- 3.Check that internal wiring to the printed circuit board are all connected.
- 4.Check that the potentiometer connections are intact and that it is functioning properly.

SPEED CONTROL ERRATIC OR ALWAYS AT HIGH SPEED ONLY :

- 1.Check rapid micro switch. Make sure it is not stuck. If its position is too high up, lightly tap on it to lower.
- 2.Check V.R. Is in good connection and proper function.

BREAKER ALWAYS KICKS OUT ON POWER FEED UNIT UNDER NORMAL USAGE :

Short circuit in the armature, need to be replaced new armature.

CURRENT LEAKAGE :

- 1.Check limits switch assembly for possible short.
- 2.check armature by first removing the brush cap.
- 3.Measure for short with an ohmmeter across the carbon brush and the outer cover of the power feed unit.