

NEON-SS FM

TOUCH YOUR DREAMS

NEON

NEON-SS FM
INSTRUCTION MANUAL

FM



1 Introduction

Congratulations, you now own one of the most unique and revolutionary radio control systems in the world. The Neon 3 was created for the beginner and seasoned R/C enthusiast to grow with your needs and skill level. The basic Neon can be upgraded with a variety of features like;

- A 4th channel three position switch
- Dual Rates on channels 1 and 2
- ATV's on channel 1, 2 and 3
- A trainer port and switch package

Any way you choose to customize your Neon, you are sure to be satisfied with the performance on this unique system.

Table of contents

	1. Introduction
	2. Features and Specifications
Page 2	Transmitter Options
	3. System Components
	Receiver Servo (Standard version, Micro version) Accessories, all systems
Page 3	4. Set-up and Operation
	Transmitter
	Reading the LED Battery Indicators Recharging Nicad batteries
Page 4	Installing Transmitter Batteries To install or change the batteries in your NEON
	Transmitter antenna Elevon/V-tail mix Servo Reversing Gimbal stick length adjustment Gimble stick tension adjustment
Page 5	Throttle Function
	5. Installation of Receiver and Servos
	Turning on your system Servo trim settings
Page 6	Range check Checking servo operation
	6. NEON Transmitter Option Installation Directions
Page 7	Trainer Port and Switch Installation ATV Board Installation
Page 8	Dual Rate Switch Installation 4th Channel Three Position Switch Accessory Installation

2 Features and Specifications

Transmitter

- Single Stick 3 channel, (upgradeable to 4 channel) FM proportional system
- Dual axis precision gimbal
- Adjustable gimbal stick length
- Adjustable gimbal stick tension
- 3 LED battery status indicators
- Charging jack for optional internal Nicad battery
- Servo reversing for all channels
- Elevon or V-tail mixing function
- Proportional 3rd. channel slide switch
- Channel 1 and 2 trim levers

Options

- Channel 4 three position switch, part # 54301
- Channel 1,2 and 3 ATV function, part # 54302
- Trainer plug and switch, part # 54303
- Channel 1 and 2 Dual Rate function part # 54304
(Must use optional part# 54304, ATV function in addition to this option)

3 System Components

Receiver

Currently there are two popular receivers used in the Neon 3 packages.

Deluxe Version includes : Electron 6 channel Dual Conversion 6 channel FM receiver

- Size: 45.5 x 22.5 x 15.0 (mm) / 1.79 x 0.88 x 0.59 (inch)
- Weight : 17g(0.6oz) without X-tal

Micro version includes : HFS-04MG 4 channel Single Conversion 4 channel FM receiver

- Size: 25 x 37.5 x 16 (mm) / 0.98 x 1.47 x 0.62 (inch)
- Weight : 15.9g (.55oz)

Servo

Currently there are two popular servos choices offered in the Neon 3 packages.

Deluxe Version includes : (2) HS-81 micro servos

- Speed : .11(4.8V) /.10sec(6.0V)
- Torque : 2.6(kg/cm) / 36oz at 4.8V
3.0(kg/cm) / 41oz at 6.0V
- Size : 30 x 12 x 30(mm) / 1.2 x 0.47 x 1.2(inch)
- Weight : .58oz/16.6g

Micro version includes :(2) HS-55 sub-micro servos

- Speed : .17(4.8V) /.14sec(6.0V)
- Torque : 1.1(kg/cm) / 15oz at 4.8V
1.3(kg/cm) /18oz at 6.0V
- Size : 23 x 12 x 24(mm) / 0.90 x 0.45 x 0.94(inch)
- Weight : .28oz/8.0g

Accessories

One CG-25 or CG-22A overnight wall charger, part # 43025 or # 43022

One Switch harness, part # 54403

One AAA receiver battery box, part # 54402

4 Set-up and Operation


Transmitter

Opening the case

The case of your Neon is unique because it does not have the traditional screws holding it together.


Instead, we have created a "pull apart" case to facilitate access to the inside components.

To open your case, unscrew the antenna and remove it, slide the tabs located at the bottom corners off and gently pull the bezel at the base of the antenna up, and then remove the crystal (See Image). Now, separate the two case half's while being careful of the internal wiring harness to the throttle switch, unplug the wires leading to the throttle switch, and you can now access the internal components to add optional feature packages, reverse your servos, or change the battery out.




Reading the LED Battery Indicators

There are three indicator lights on the face of the radio marked High (green), Mid (amber) and Low (red). These relate to the condition of your transmitter battery. Please pay attention to these LEDs and stop flying when the red "Low" light is on.



Recharging Nicad batteries

The Deluxe NEON version transmitter is supplied with rechargeable Nicad batteries. Before using the radio, plug the supplied 110V. CG-25 or 220V. CG-22A overnight wall charger into a normal household AC wall socket. There are two leads on the CG-25 or CG-22A, the round one plugs into the socket on the lower left side of the transmitter. The green light on the CG-25 or CG-22A should glow, confirming charging is taking place; leave it on charge for at least 18 hours. Once fully charged, the transmitter should operate for about 120 minutes. Typically you will charge the radio up overnight before flying the next day. Do not leave the radio connected to the wall charger for over 36 hours or permanent damage to the transmitter battery pack may occur.




Installing Transmitter Batteries

Hitec offers the NEON in several versions, some complete with rechargeable transmitter batteries and some "dry" using "alkaline" (non-rechargeable) batteries. Should your system come "dry", consider the option of adding individual NiCad cells to your battery holder or replacing the battery holder with the optional Hitec NiCad battery pack, part number 58207. Both packs can be charged with Hitec's overnight wall chargers as noted above.

To install or change the batteries in your NEON

Split the case as described in section 4, Set-up and Operation on page 3,
 Remove the battery holder.
 Install batteries as shown in image.
 Reinstall the battery holder.

Note: The NEON transmitter charging circuitry uses a Diode. This means Hitec cannot recommend the use of "peak" chargers to charge your NiCad pack within the NEON case.



Transmitter antenna

Always have the antenna screwed in securely and fully extended when the transmitter is on, except when doing a range check.

Elevon/V-tail mix

Your Neon transmitter has a "built-in" channel 1 and 2 mix for flying wing "elevon" controls and "V-tail" ruddervator controls.


This function is activated with the slide switch on the face of the radio.

There are two factors that determine what direction the servo will move when the Elevon or V-tail mixing is selected.

- Whether the servo is plugged into the channel 1 or 2 port on the receiver
- The servo "direction of rotation", selectable within the transmitter case.

Using these two functions it is possible to have the two servos move in the directions required for Elevon or V-tail/Ruddervator control.


If your ailerons and elevator controls are reversed you will need to reverse one or both of the servo reversing plugs on the main PC board (described below) . If only one of the controls is reversed and you cannot get it set right with the servo reversing function, you will need to swap the servo leads in the receiver. I.E. plug the servo in channel #1 into channel #2 and channel #2 into channel #1.



Servo Reversing

After removing the back of the case you will find four plugs (there are four plugs if you have the optional 4th channel feature).


Simply unplug and rotate the connector 180 degrees, plug it back onto the board and the servo throw for that servo, is now reversed.



Gimbal stick length adjustment


The gimbal stick is adjustable to suit your personal preference.

Hold the bottom half of the knurled knob and twist the top half counterclockwise to loosen, adjust the length to your satisfaction and twist the two pieces to lock them together.



Gimbal stick tension adjustment


The spring tension of the gimbal is also adjustable. Remove the back of the transmitter case to expose the gimbal mechanism. Note the two screws associated with the springs. To soften the effect of the springs, turn the screws counterclockwise, to tighten the "feel" of the gimbal stick, turn the screws clockwise.



Throttle Function

The Neon 3 features a slide switch located on the back of the transmitter, it is adjusted with your left index finger as your hand naturally wraps around the radio case. Use this switch to get proportional control of your throttle servo, or ESC, (Electronic Speed Control.)


Note: All ESC's connect to your receiver in the channel 3 port.




5 Installation of Receiver and Servos

Please refer to the aircraft manufacturers instructions on servo, receiver and battery placement within your aircraft.
Channel 1 is Aileron or Rudder / Channel 2 is Elevator / Channel 3 is Throttle / Channel 4 is optional

Deluxe version



Micro Version




Turning on your system

Before turning on your transmitter when at a flying field, ask about frequency control. If you turn on your transmitter when another person is flying on the frequency your radio is on, the other plane will crash and you will be responsible.

Always turn the transmitter on first, then turn on the receiver. Do the opposite to power down your system, doing this will avoid damage to your servos and linkages.


Servo trim settings

There are two trim levers on the face of the transmitter associated with channel 1, the aileron or rudder and channel 2, elevator. Center these trim levers before installing your servos. These trim levers are used to make minor trim adjustments while in flight, so the aircraft can fly straight and level. Do not use these trims to center a flight control surface while the plane is on the ground or before the first flight, those adjustments should be made with the control linkages before the plane flies.



Range check

Before flying your model, conduct a range check. Turn everything on and collapse the transmitter antenna so that one section remains exposed. While holding the transmitter, walk away from the model, you should have full control over the model without any glitching at least 65 to 75 feet away. If your range is less than this, do not fly, as there would appear to be a problem! Contact the Hitec service department and we will try to help you.




Checking servo operation

Proper servo linkage geometry is important, all control rods should be at a 90 degree angle to the servo case.

6 NEON Transmitter Option Installation Directions.


Trainer Port and Switch Installation

1. Open the case as instructed on page 3 and disconnect the throttle switch harness plug from the main board.
2. Disconnect the power from the radio by removing the battery holder or unplugging and removing the Nicad battery pack.
3. Twist out and remove the plastic cover from the back side of the case so the trainer plug can be accessed after the case is closed. Clean up the edges with a hobby knife.
4. Plug the 6 wire plug into the port marked "trainer" and route the wires so they will not be pinched when the case is re-assembled.
5. Pop the plastic plug out from the top right of the Tx case and install the switch by removing both small nuts, sliding the switch up through the hole and securing both nuts so the top nut "jams" the bottom one tight. Taking care to orient the switch so when the Tx is resting in your hand in the flying position, the switch is pulled towards you and snaps back away from you when released.
6. Route the wires so they will not be pinched when the case is re-assembled.
7. Place the plug port PC board on the four screw posts and use the four screws to secure it.
8. Re-install the battery.
9. Plug the throttle back in.
10. Taking care not to pinch any wires, slide the top of the case half's together then snap the bottom together. Reinstall the antenna, antenna bezel, crystal and the lower case tabs.
11. All done? Range check your radio and go fly!



ATV Board Installation


1. Open the case as instructed on page 3 and disconnect the throttle switch harness plug from the main board.
2. Disconnect the power from the radio by removing the battery holder or unplugging and removing the Nicad battery pack.
3. Remove the four screws holding in the large brown PC board in the illustration.
4. Without unplugging anything on the board, you should be able to shift the board up out of the way about 1 inch.
Note: slide the white wire next to the antenna screw post out of the slot.
5. Pop the "cover" out from the three small holes and place the ATV board on the two screw posts. Secure the board with the two supplied screws, be sure to tighten the screws up snug.
6. Taking care to route the wires under the boards as much as possible, re-install the four screws holding down the large brown PC board.
7. Slide the white wire next to the antenna screw post into the slot and out of the way of the antenna as it is reinserted.
8. Re-install the battery.
9. Plug the throttle back in.
10. Taking care not to pinch any wires, slide the top of the case half's together then snap the bottom together. Reinstall the antenna, antenna bezel, crystal and the lower case tabs.
11. All done? Range check your radio and go fly!



Dual Rate Switch Installation


Note: ATV board component must be installed prior to adding the Dual Rate Switch.

1. Open the case as instructed on page 3 and disconnect the throttle switch harness plug from the main board.
2. Disconnect the power from the radio by removing the battery holder or unplugging and removing the Nicad battery pack.
3. Remove the four screws on the front of the radio that hold the gimbal in.
4. Remove the plug in the hole marked, D/R
5. Slide the Dual Rate Switch into the hole and secure with the lock nut.
6. Reinstall the gimbal.
7. Route the wire and attach the white connector into the plug marked DR SW on the large brown PC board.
8. Re-install the battery.
9. Plug the throttle back in.
10. Taking care not to pinch any wires, slide the top of the case half's together then snap the bottom together.
Reinstall the antenna, antenna bezel, crystal and the lower case tabs.
11. All done? Range check your radio and go fly!



4th Channel Three Position Switch Accessory Installation

1. Open the case as instructed on page 3 and disconnect the throttle switch harness plug from the main board.
2. Disconnect the power from the radio by removing the battery holder or unplugging and removing the Nicad battery pack.
3. Remove the plug in the hole marked, AUX.
4. Slide the Switch into the hole and secure with the lock nut.
5. Route the wire and attach the connector into the plug marked CH-4 on the large brown PC board.
6. Re-install the battery.
7. Plug the throttle back in.
8. Taking care not to pinch any wires, slide the top of the case half's together then snap the bottom together.
Reinstall the antenna, antenna bezel, crystal and the lower case tabs.
9. All done? Range check your radio and go fly!



NEON SS FM
OPTIONAL VERSION

CE 0681

Austria, Belgium, Denmark, Finland,
France, Germany, Greece, Iceland,
Ireland, The Netherlands, Italy, Spain,
Norway, Portugal, United Kingdom,
Luxembourg, Sweden, Switzerland

www.hitecrd.com

English (영어)

