



Replacement Parts

Table with columns: Stock #, Description, and quantity. Lists various replacement parts like bearings, batteries, connectors, and chassis components.

Table with columns: Stock #, Description, and quantity. Lists stock items like upper arm sets, tire sets, wheel sets, and speed controls.

HARDWARE

Table with columns: Stock #, Description, and quantity. Lists hardware items like ball studs, E-clips, FH ST screws, machine screws, motor mount screws, shock O-rings, and servo tapes.

OPTIONALS


Table with columns: Stock #, Description, and quantity. Lists optional parts like NIMH batteries, motor connectors, carbon fiber battery straps, clear bodies, carbon fiber chassis brace rods, CV drive shafts, carbon fiber main drive shafts, spur gears, aluminum knuckle sets, aluminum heatsink motor mounts, pinion gears, aluminum shock sets, soft springs, hard springs, adjustable turnbuckle sets, and chrome wheels.

To order replacement parts or to send your model in for repairs covered under warranty, you should send your model to DuraTrax's authorized U.S. repair facility:

Hobby Services
3002 N. Apollo Drive, Suite 1, Champaign, Illinois 61822
Attn: Service Department
Phone: (217) 398-0007
9:00 A.M. - 5:00 P.M. Central Time M-F
E-Mail: hobbyervices@hobbico.com

\* indicates Stress-Tech™ part

Hardware Chart



This parts list shows the key number, part description and parts bag stock number for ordering. If there are multiple stock numbers listed, that particular part is available in several places. Refer to the replacement parts bag list for the contents of each parts bag.

Main parts list table with columns: #, Item Description, Stock #, and quantity. Lists numerous parts including hinges, servo arms, steering links, chassis brace rods, body posts, clips, axle stubs, universal balls, slider shafts, slider shaft females, spur gears, motor mounts, motor w/ connectors, lower arms, upper arms, front bumpers, front skids, steering drag links, bellcrank post right/left, bellcrank brace, bellcrank post, steering/toe in link, main driveshafts, main driveshaft support, rear drive couplers, front drive couplers, rear diff pinion gear, front diff pinion gear, front diff pinion gear, left/right knuckles, wheels, tires, lower shock mount pins, shock cartridges, shock ends, shock springs, shock shafts, shock pistons, shock springs, 6x10mm ball bearings, bellcrank bushings, rear bumpers, rear skids, rear differential covers, antenna caps, shock preload clips, differential cases, main differential gear, small bevel gear, differential pin T2, differential pin T1, shock cap, shock bladder, shock body, shock o-ring, and double-sided tape.

**DURATRAX**

# MINI QUAKE

