




CVD™ INSTRUCTIONS FOR ASSEMBLY & MAINTENANCE

#304 8/98

Thank you for purchasing the MIP CVD™s (CONSTANT VELOCITY DRIVES). This product is exemplary of MIP's effort to design and manufacture R/C accessories that make a difference in your racing. (CVD is a Trademark of MIP, 1992)

Please follow instructions completely:

1. Spread a thin layer of MIP CVD™ lube on couplings, and insert into axles.
2. Slide completed axles into bone with the cross holes aligned.
3. Insert the cross pin, and make sure it is evenly spaced on both sides of the bone.
4. Angle and turn CVD™ so the set screw can be screwed in with the supplied Allen wrench. Always use the included MIP thread lock on the set screws.
5. Install completed CVD™s using shims as needed on axle to adjust dog bone spacing in outrives. Some CVD™ kits do not require axle shims. Insert the axle cross pins and complete assembly same as stock. **Be careful not to over tighten wheel nuts and bind axles.**



CVD™ Rebuild Tip:
When rebuilding your CVD™s install new set screws sold in hardware package and use MIP Thread Lock.

Send a SASE for a free catalog, or visit www.miponline for a complete listing of all MIP products.

Moore's Ideal Products • 830 W. Golden Grove Way • Covina, CA. 91722 • USA

[RETURN TO LIST OF INSTRUCTION SHEETS](#)